

STORMCOVER FITTING INSTRUCTIONS



1)
Unpack the Storm-
cover roof and sides
next to your Caravan
or Motorhome



2)
Roll the Roof Section
over the roof of your
Caravan or
Motorhome



3)
Secure the roof
section in position
with the straps sewn
onto the Stormcover

STORMCOVER FITTING INSTRUCTIONS



4)
Zip the sides of the Stormcover onto the roof section and press down hook and loop protective strip



5)
If you have ordered a separate door panel this can be fully zipped out for easy RV access



6)
For complete RV coverage separate draw bar covers can be made for your Caravan or Motorhome