

SUNCOVER FITTING INSTRUCTION

Sharp edges are your covers worst enemy. Cover all sharp edges before installing cover.

ROOF is rolled inside out from back to front , MARKED WITH BLUE LABEL. Put on front of van and unroll towards back. Attach straps to secure roof into place.

RIGHT SIDE RED LABEL . LEFT SIDE YELLOW LABEL . SIDES rolled up from back to front , put at front of van and unroll towards back. Hold side panel zip up to line up with roof zip and gently join zips together. Fold over loop tape to attach to hook tape to fully cover and protect zip teeth from elements.

Do not yank or pull zip aggressively the zipper teeth can break out if excessive force is used , if this happens zip is designed to work with 3-4 teeth missing. Zip teeth breaking is not covered by warranty .

After both sides zipped on attach straps underneath van . Do up tension straps at rear. Do not over tighten straps.

Use fabric glue or reinforce patch kit (depending on fabric) to repair or re-inforce cover in case of tear or sharp edges wearing through cover. Cover will not reach life expectancy if holes are not patched up .